Malyugín Ríng™

Distributed by:




MaxiMed Sàrl Pl. Hôtel de Ville 8 1040 Echallens

T. 021 886 07 00 F. 021 886 07 07 info@maximed.ch www.maximed.ch

SURGICAL / DIAGNOSTICS / LASERS


Ring Placement




With viscoelastic in the Anterior Chamber inject the Ring approximately 2mm forward, then engage the distal iris margin.



Lay proximal scroll on anterior iris.




Inject while simultaneously retracting the injector. "Toeing" the injector down eases placement of the lateral scrolls.




Use a Osher/Malyugin Ring Manipulator to place the proximal scroll.


Ring Removal




Use a Osher/Malyugin Ring Manipulator to disengage the distal scroll.



Place the distal scroll onto anterior iris.




Move the proximal scroll toward the center of the pupil, and a bit anterior to disengage.



Place the proximal scroll onto anterior iris.



Position the injector's platform on the right under the ring, move under the proximal scroll, then move the injector button forward.



Move the injector button back to remove the ring. Stop when the left scroll rides above the cannula, then remove the "assembly".